

Installation Instructions



Watch our video before beginning: www.edge-ink.com/installation

Installation time:

About 5-10 minutes

What you need:

- Small bowl with 1.5 cups of water (a cereal bowl works great)
- Liquid dish soap
- Alcohol wipe
- Your Garmin Edge computer
- Your awesome Edge-Ink frame

Prepare your solution:

1. Fill your bowl with 1.5 cups of water.
2. Add 1 drop of dish soap (be careful not to use too much).
3. Swirl the soap/water mixture with your fingers to distribute the soap. You should get some bubbling at the surface.

Prepare your Garmin Edge:

1. Power off your device.
2. Clean the screen with the provided alcohol wipe.

Install your Edge-Ink frame:

*****We strongly recommend you do a practice installation with the test frame provided!*****

1. Wet your fingers in the soap solution. Continue to wet them throughout the installation process.
2. Using your finger, wet the screen of your Garmin Edge with some of the soap solution.
3. With wet fingers, bend the decal at the corner and carefully peel away the Edge-Ink frame from the backing (be sure to only handle the adhesive side of the frame with wet fingers).
4. Dip the Edge-Ink frame in the soap solution.
5. Lay the Edge-Ink frame on the screen of your Garmin Edge.
6. Gently move the frame into the correct position, carefully lining up all edges.
7. Using a soft cloth, dab the screen/frame lightly to remove some of the excess solution.
8. Holding the frame in place with one finger, gently smooth the frame with another finger, being careful not to move it.
9. Use a soft cloth to gently dab the screen again, absorbing most of the excess solution.
10. Double check that the frame is perfectly aligned (If not, you should still be able to move it with your fingers. If you cant move it, peel it back and start over).
11. Allow 1-2 hours for it to dry, wait for 24 hours before using it on a ride.
12. Go for a ride and show off your newly customized Garmin Edge!

Tips:

- Use the test frame first to practice, peel it away before it dries, clean the screen again and install the real deal.
- Install your frame in a well lit, dust free area.
- Continue to re-wet your fingers with the soap solution throughout the installation process.